


ARA

HYDRAULIC OPERATOR FOR FOLDING DOORS **OPÉRATEUR HYDRAULIQUE POUR PORTES ACCORDEONS**

**SEA S.p.A.****Zona Industriale Sant'Atto - Teramo - 64100 - (ITALY)****Tel. +39 0 861 588341 (r.a.) - Fax +39 0 861 588344**www.seateam.com

1 - FEATURES - CARACTERISTIQUES

- **ARA** is a hydraulic operator to be installed on a folding door; it opens folding doors using a telescopic arm in a harmonious and linear way
- **ARA** est un opérateur hydraulique à installer sur une porte accordéon; grâce au bras télescopique, la porte accordéon s'ouvre avec un mouvement linéaire et harmonieuse.

COMPONENTS - COMPOSANTS

- ① Drive shaft
Tige transmission
- ② Oil filler caps
Bouchons remplissage d'huile
- ③ Oil level caps
Bouchons niveau d'huile
- ④ By-pass valves
Vannes by-pass
- ⑤ Release screw
Vis de déverrouillage





Fig. 1

USING GRAPHIC - GRAPHIQUE UTILISATION



DIMENSIONS (mm) - DIMENSIONS (mm)





Fig. 2

TECHNICAL DATA - DONNEES TECHNIQUES		TECHNICAL DATA - DONNEES TECHNIQUES	
POWER SUPPLY - ALIMENTATION	230 V~ ± 5% - 50/60 Hz	CYCLES/HOUR - CYCLES/HEURE	60 (T = 20°C) *
ABSORBED CURRENT - COURANT ABSORBÉ	1,1 A	IRREVERSIBILITY - IRRÉVERSIBILITÉ	YES (AC TYPE) - NO (SB TYPE)
POWER - PUISSANCE	220 W	SLOWDOWN - RALENTISSEMENT	ELECTRONIC - ÉLECTRONIQUE
MOTOR SPEED - VITESSE MOTEUR	1430 RPM	THERMOPROTECTION	130°
WORKING TEMPERATURE TEMPÉRATURE DE FONCTIONNEMENT	- 20°C - + 55° C	MAX DOOR WIDTH LARGEUR MAX. PORTE	L = 1m x H = 5m (AC TYPE) L = 1,5m x H = 5m (SB TYPE)
PROTECTION DEGREE - DEGRÉ PROTECTION	IP55	CAPACITOR - CONDENSATEUR	12,5 µF
MANUAL RELEASE - DÉVERROUILLAGE MAN.	YES	OPERATOR WEIGHT - POIDS OPÉRATEUR	12 Kg

* THE INDICATED FREQUENCY OF USE IS VALID ONLY FOR THE FIRST OPERATING HOUR AND AT A 20°C TEMPERATURE

* LA FRÉQUENCE D'UTILISATION EST VALIDE SEULEMENT POUR LA PREMIÈRE HEURE ET À UNE TEMPÉRATURE AMBIANTE DE 20° C

2 - TYPICAL INSTALLATION - INSTALLATION TYPIQUE




3 - PRELIMINARY CHECKS - VÉRIFICATIONS PRÉLIMINAIRES

● BEFORE INSTALLATION, CHECK THAT:

- THE DOOR STRUCTURE IS SUFFICIENTLY STRONG, THAT THE HINGES (IN FIG. 4) ARE EFFICIENT AND THAT THERE IS NO FRICTION BETWEEN FIXED AND MOVING PARTS;
- THE PASSAGE OF THE ELECTRIC CABLES COMPLIES WITH THE SAFETY LAWS IN FORCE;
- THE MECHANICAL STOPS IN CLOSING ARE INSTALLED AND WELL FIXED ON THE GROUND, TO AVOID OVERTRAVEL OF THE LEAF OR GEARMOTOR;



● AVANT DE PROCÉDER À L'INSTALLATION, VÉRIFIEZ QUE:

- LA STRUCTURE DE LA PORTE EST SUFFISAMMENT SOLIDE, QUE LES CHARNIÈRES (FIG. 4) SONT EFFICACES ET QU'IL N'Y A PAS DE FROTTEMENT ENTRE PIÈCES FIXES ET MOBILES;
- LE TRACÉ DES CÂBLES ÉLECTRIQUES SOIT CONFORME AUX DISPOSITIONS DE LOI SUR LA SÉCURITÉ;
- IL Y A DES BUTÉE MÉCANIQUE EN FERMETURE, BIEN FIXÉE AU SOL, POUR ÉVITER LA SURCOURSE DU VANTAIL OU DU MOTORÉDUCTEUR ;




4 - RIGHT/LEFT MOUNTING - MONTAGE DROIT/GAUCHE

MONTING ON LEFT DOOR MONTAGE SUR PORTE GAUCHE



MOUNTING ON RIGHT DOOR MONTAGE SUR PORTE DROITE



- TO CHANGE THE MOUNTING DIRECTION, OVERTURN THE OPERATOR KEEPING BY-PASS VALVES AND RELEASE LEVER ON THE VISIBLE SIDE

- POUR CHANGER LE SENS DE MONTAGE, RENVERSER L'OPÉRATEUR EN GARDANT VANNES DE BY-PASS ET LEVIER DU CÔTÉ VISIBLE

5 - ASSEMBLY DIAGRAM - SCHEMA DE MONTAGE





Fig. 8

● **EXAMPLE OF ASSEMBLY ON THE RIGHT DOOR.**

FOR ASSEMBLY ON THE LEFT DOOR, OVERTURN THE OPERATOR (CHAPTER 4) AND PROCEED IN THE SAME WAY

● **EXEMPLE DE MONTAGE SUR LA PORTE DROITE.**

POUR MONTAGE SUR PORTE GAUCHE, RENSER L'OPÉRATEUR (CHAPITRE 4) ET PROCÉDER DE LA MÊME FAÇON



6 - INSTALLATION

- FOLLOW THE ASSEMBLY INSTRUCTIONS IN FIG. 8, PAYING ATTENTION TO THE CORRECT POSITIONING OF THE OPERATOR (RELEASE LEVER AND BY-PASS VALVES MUST BE VISIBLE AS IN FIG. 5 OR FIG. 7).
 - IF NECESSARY, SHORTEN THE TELESCOPIC ARM TO THE APPROPRIATE SIZE.
 - THE TELESCOPIC ARM MUST BE INSERTED INSIDE THE HOUSING ON THE OPERATOR (*); THE OTHER SIDE MUST BE FIXED TO THE DOOR THROUGH THE BRACKET; MAKE SURE IT IS POSITIONED AT THE MIDDLE OF THE LEAF LENGTH (FIG. 9)
 - * IT IS NECESSARY TO UNLOCK THE OPERATOR TO MOVE THE TELESCOPIC ARM IN ORDER TO FIND THE CORRECT POSITIONING OF THE BRACKET ON THE LEAF
 - MAKE SURE THAT THE DIMENSIONS IN FIG. 10 AND FIG. 11 ARE RESPECTED
 - RE-LOCK THE OPERATOR USING THE APPROPRIATE RELEASE LEVER, ONCE INSTALLATION IS COMPLETE
 - REMOVE **THE RED TRANSPORT CAP UP LOCATED** (FIG. 14) AND REPLACE IT WITH THE BLACK BREATHER CAP SUPPLIED (FIG. 15)
-
- SUIVRE LES INSTRUCTIONS DE MONTAGE EN FIG. 8, EN FAISANT ATTENTION AU POSITIONNEMENT CORRECT DE L'OPÉRATEUR (LEVIER DE DÉVERROUILLAGE ET VANNES BY-PASS VISIBLES COMME EN FIG. 5 OU FIG. 7).
 - SI NÉCESSAIRE, RACCOURCISSEZ LE BRAS TÉLESCOPIQUE À LA TAILLE APPROPRIÉE.
 - LE BRAS TÉLESCOPIQUE DOIT ÊTRE INSÉRÉ, D'UN CÔTÉ, À L'INTÉRIEUR DU LOGEMENT DE L'OPÉRATEUR (*), ET L'AUTRE CÔTÉ DOIT ÊTRE FIXÉ À LA PORTE À L'AIDE DE L'ÉTRIER; FAIRE ATTENTION QU'IL SOIT POSITIONNÉ À MI-CHEMIN SUR LA LONGUEUR DU VANTAIL (FIG. 9)
 - * UNE FOIS INSÉRÉ, POUR DÉPLACER LE BRAS TÉLESCOPIQUE AFIN DE TROUVER LE BON POSITIONNEMENT DU SUPPORT SUR LA PORTE, IL EST NÉCESSAIRE DE DÉVERROUILLER L'OPÉRATEUR
 - ASSUREZ-VOUS QUE LES DIMENSIONS DE LA FIG. 10 ET DE LA FIG. 11 SONT RESPECTÉES
 - REBLOQUEZ L'OPÉRATEUR À L'AIDE DU LEVIER DE DÉVERROUILLAGE, UNE FOIS L'INSTALLATION EST TERMINÉE
 - RETIREZ LE **BOUCHON DE TRANSPORT ROUGE SITUÉ EN HAUT** (FIG. 14) ET REMPLACEZ-LE PAR LE BOUCHON NOIR DE VENTILATION FOURNI (FIG. 15)




Fig. 14




Fig. 15

● THE RED CAP IS ON BOTH SIDES OF THE OPERATOR. AFTER INSTALLATION, REMOVE **ONLY THE TOP CAP!**

● LE BOUCHON ROUGE SE TROUVE SUR LES DEUX CÔTÉS DE L'OPÉRATEUR. APRÈS L'INSTALLATION RETIRER **UNIQUEMENT LE BOUCHON SUPÉRIEUR!**

7 - BY-PASS VALVES - VANNES BY-PASS




Fig. 16



GREY - GRIS
THRUST ADJUSTMENT IN CLOSING
RÉGLAGE POUSSÉE EN FERMETURE



YELLOW - JAUNE
THRUST ADJUSTMENT IN OPENING
RÉGLAGE POUSSÉE EN OUVERTURE



THE VALVES MUST BE ADJUSTED IN PARALLEL AND THERE MUST BE NO DIFFERENCES IN SETTING BETWEEN OPENING AND CLOSING



LES VANNES DOIVENT ÊTRE RÉGLÉES EN PARALLÈLE ET IL NE DOIT Y AVOIR AUCUNE DIFFÉRENCE DE RÉGLAGE ENTRE L'OUVERTURE ET LA FERMETURE

ADJUST THE OPENING AND CLOSING FORCE OF THE DOOR IN ORDER TO RESPECT THE FORCE DIAGRAM (AS PER EN12453 STANDARD); HOWEVER, THE THRUST FORCE MUST NEVER EXCEED 15 KgF

RÉGLER LA FORCE D'OUVERTURE ET DE FERMETURE DE LA PORTE AFIN DE RESPECTER LE DIAGRAMME DE FORCE (SELON LA NORME EN12453); CEPENDANT, LA FORCE DE POUSSÉE NE DOIT JAMAIS DÉPASSER 15 KgF

GENERAL NOTICE FOR THE INSTALLER AND THE END-USER

1. **Read carefully these Instructions before beginning to install the product.** Store these instructions for future reference
2. Don't waste product packaging materials and /or circuits
3. This product was designed and built strictly for the use indicated in this documentation. Any other use, not expressly indicated here, could compromise the good condition/operation of the product and/or be a source of danger. SEAS.p.A. declines all liability caused by improper use or different use in respect to the intended one.
4. The mechanical parts must comply with Directives: Machine Regulation 2006/42/CE and following adjustments, Low Tension (2006/95/CE), Electromagnetic Consistency (2004/108/CE); Installation must respect Directives: EN12453 and EN12445.
5. Do not install the equipment in an explosive atmosphere.
6. SEAS.p.A. is not responsible for failure to observe Good Techniques in the construction of the locking elements to motorize, or for any deformation that may occur during use.
7. Before attempting any job on the system, cut out electrical power and disconnect the batteries. Be sure that the earthing system is perfectly constructed, and connect to it the metal parts of the gate
8. Use of the indicator-light is recommended for every system, as well as a warning sign well-fixed to the frame structure.
9. SEA declines all liability concerning the automated system safety and efficiency, if components used are not produced by SEA
10. For maintenance, strictly use original parts by SEA.
11. Do not modify in any way the components of the automated system.
12. The installer shall supply all information concerning the system manual functioning in case of emergency and shall hand over to the user the warnings handbook supplied with the product.
13. Do not allow children or adults to stay near the product while it is operating. The application cannot be used by children, by people with reduced physical, mental or sensorial capacity or by people without experience or necessary training. Keep remote controls or other pulse generators away from children, to prevent involuntary activation of the system.
14. Transit through the leaves is allowed only when the gate is fully open.
15. The User must not attempt to repair or to take direct action on the system and must solely contact qualified SEA personnel or SEA service centers. The User can apply only the manual function of emergency.
16. The power cables maximum length between the central engine and motors should not be greater than 10 m. Use cables with 2,5 mm² section. Use double insulation cable (cable sheath) to the immediate vicinity of the terminals, in particular for the 230V cable. Keep an adequate distance (at least 2.5 mm in air), between the conductors in low voltage (230V) and the conductors in low voltage safety (SELV) or use an appropriate sheath that provides extra insulation having a thickness of 1 mm.

TERMS OF SALE

EFFICACY OF THE FOLLOWING TERMS OF SALE: the following general terms of sale shall be applied to all orders sent to SEAS.p.A. All sales made by SEA to all customers are made under the prescription of this terms of sales which are integral part of sale contract and cancel and substitute all apposed clauses or specific negotiations present in order document received from the buyer.

GENERAL NOTICE The systems must be assembled exclusively with SEA components, unless specific agreements apply. Non-compliance with the applicable safety standards (European Standards EN12453 – EN 12445) and with good installation practice releases SEA from any responsibilities. SEA shall not be held responsible for any failure to execute a correct and safe installation under the above mentioned standards.

1) PROPOSED ORDER The proposed order shall be accepted only prior SEA approval of it. By signing the proposed order, the Buyer shall be bound to enter a purchase agreement, according to the specifications stated in the proposed order. On the other hand, failure to notify the Buyer of said approval must not be construed as automatic acceptance on the part of SEA.

2) PERIOD OF THE OFFER The offer proposed by SEA or by its branch sales department shall be valid for 30 solar days, unless otherwise notified.

3) PRICING The prices in the proposed order are quoted from the Price List which is valid on the date the order was issued. The discounts granted by the branch sales department of SEA shall apply only prior to acceptance on the part of SEA. The prices are for merchandise delivered ex-works from the SEA establishment in Teramo, not including VAT and special packaging. SEA reserves the right to change at any time this price list, providing timely notice to the sales network. The special sales conditions with extra discount on quantity basis (Qx, Qx1, Qx2, Qx3 formula) is reserved to official distributors under SEA management written agreement.

4) PAYMENTS The accepted forms of payment are each time notified or approved by SEA. The interest rate on delay in payment shall be 1.5% every month but anyway shall not be higher than the max. interest rate legally permitted.

5) DELIVERY shall take place, approximately and not peremptorily, within 30 working days from the date of receipt of the order, unless otherwise notified. Transport of the goods shall be at Buyer's cost and risk. SEA shall not bear the costs of delivery giving the goods to the carrier, as chosen either by SEA or by the Buyer. Any loss or damage of the goods during transport, are at Buyer's cost

6) COMPLAINTS Any complaints or claims shall be sent to SEA within 8 solar days from receipt of the goods, proved by adequate supporting documents as to their truthfulness

7) SUPPLY The concerning order will be accepted by SEA without any engagement and subordinately to the possibility to get its supplies of raw material which is necessary for the production; Eventual completely or partially unsuccessful executions cannot be reason for complaints or reservations for damage. SEA supply is strictly limited to the goods of its manufacturing, not including assembly, installation and testing. SEA, therefore, disclaims any responsibility for damage deriving, also to third parties, from non-compliance of safety standards and good practice during installation and use of the purchased products.

8) WARRANTY The standard warranty period is 12 months. This warranty time can be extended by means of expedition of the warranty coupon as follows:

SILVER: The mechanical components of the operators belonging to this line are guaranteed for 24 months from the date of manufacturing written on the operator.

GOLD: The mechanical components of the operators belonging to this line are guaranteed for 36 months from the date of manufacturing written on the operator.

PLATINUM: The mechanical components of the operators belonging to this line are guaranteed for 36 months from the date of manufacturing written on the operator. The base warranty (36 months) will be extended for further 24 months (up to a total of 60 months) when it is acquired the certificate of warranty which will be filled in and sent to SEAS.p.A. The electronic devices and the systems of command are guaranteed for 24 months from the date of manufacturing. In case of defective product, SEA undertakes to replace free of charge or to repair the goods provided that they are returned to SEA repair centre. The definition of warranty status is by unquestionable assessment of SEA. The replaced parts shall remain propriety of SEA. Binding upon the parties, the material held in warranty by the Buyer, must be sent back to SEA repair centre with fees prepaid, and shall be dispatched by SEA with carriage forward. The warranty shall not cover any required labour activities. The recognized defects, whatever their nature, shall not produce any responsibility and/or damage claim on the part of the Buyer against SEA. The guarantee is in no case recognized if changes are made to the goods, or in the case of improper use, or in the case of tampering or improper assembly, or if the label affixed by the manufacturer has been removed including the SEA registered trademark No. 804888. Furthermore, the warranty shall not apply if SEA products are partly or completely coupled with non-original mechanical and/or electronic components, and in particular, without a specific relevant authorization, and if the Buyer is not making regular payments. The warranty shall not cover damage caused by transport, expendable material, faults due to non-conformity with performance specifications of the products shown in the price list. No indemnification is granted during repairing and/or replacing of the goods in warranty. SEA disclaims any responsibility for damage to objects and persons deriving from non-compliance with safety standards, installation instructions or use of sold goods. The repair of products under warranty and out of warranty is subject to compliance with the procedures notified by SEA.

9) RESERVED DOMAIN A clause of reserved domain applies to the sold goods; SEA shall decide autonomously whether to make use of it or not, whereby the Buyer purchases property of the goods only after full payment of the latter.

10) COMPETENT COURT OF LAW In case of disputes arising from the application of the agreement, the competent court of law is the tribunal of Teramo. SEA reserves the faculty to make technical changes to improve its own products, which are not in this price list at any moment and without notice. SEA declines any responsibility due to possible mistakes contained inside the present price list caused by printing and/or copying. The present price list cancels and substitutes the previous ones. The Buyer, according to the law No. 196/2003 (privacy code) consents to put his personal data, deriving from the present contract, in SEA archives and electronic files, and he also gives his consent to their treatment for commercial and administrative purposes.

Industrial ownership rights: once the Buyer has recognized that SEA has the exclusive legal ownership of the registered SEA brand num.804888 affixed on product labels and / or on manuals and / or on any other documentation, he will commit himself to use it in a way which does not reduce the value of these rights, he won't also remove, replace or modify brands or any other particularity from the products. Any kind of replication or use of SEA brand is forbidden as well as of any particularity on the products, unless preventive and expressed authorization by SEA. In accomplishment with art. 1341 of the Italian Civil Law it will be approved expressly clauses under numbers: 4) PAYMENTS - 8) GUARANTEE - 10) COMPETENT COURT OF LAW

DECLARATION OF CONFORMITY DICHIARAZIONE DI CONFORMITÀ

SEA S.p.A. declares under its proper responsibility and, if applicable, under the responsibility of its authorised representative that, by installing the appropriate safety equipment and noise filtering, the products:

La SEA S.p.A. dichiara sotto la propria responsabilità e, se applicabile, del suo rappresentante autorizzato che, con l'installazione degli adeguati dispositivi di sicurezza e di filtraggio disturbi, i prodotti:

DESCRIPTION - DESCRIZIONE

MODEL - MODELLO

TRADEMARK - MARCA

ARA

11501030

SEA

(AND ALL ITS BY-PRODUCTS - E TUTTI I SUOI DERIVATI)

are built to be integrated into a machine or to be assembled with other machinery to create a machine under the provisions of Directive 2006/42/CE;

comply with the essential safety requirements related to the products within the field of applicability of the Community Directives 2014/35/UE and 2014/30/UE

sono costruiti per essere incorporati in una macchina o per essere assemblati con altri macchinari per costruire una macchina ai sensi della Direttiva 2006/42/CE;

sono conformi ai requisiti essenziali di sicurezza relativi ai prodotti entro il campo di applicabilità delle Direttive Comunitarie 2014/35/UE e 2014/30/UE

THE MANUFACTURER OR THE AUTHORIZED REPRESENTATIVE
IL COSTRUTTORE O IL RAPPRESENTANTE AUTORIZZATO

SEA S.p.A.

ZONA INDUSTRIALE SANT'ATTO

64100 - TERAMO - ITALY

+ 39 0 861 588341

www.seateam.com

PLACE AND DATE OF ISSUE

LUOGO E DATA DI EMISSIONE

TERAMO, 06/04/2022

L'Amministratore

The Administrator

Ennio Di Saverio





Automatic Gate Openers

International registered trademark n. 804888

SEA S.p.A.

Zona Industriale Sant'Atto - Teramo - 64100 - (ITALY)

Tel. +39 0 861 588341 (r.a.) - Fax +39 0 861 588344

www.seateam.com