

ARA

ISTRUZIONI SBLOCCO ESTERNO - INSTRUCCIÓN PARA DESBLOQUEO EXTERNO EXTERNAL RELEASE INSTRUCTION - INSTRUCTION DEVERROUILLAGE EXTERNE

Fig.1a





Fig.2a



OPERATORE A SINISTRA
ACTUADOR PARA IZQUIERDA
OPERATOR ON THE LEFT
OPÉRATEUR À GAUCHE

OPERATORE A DESTRA
ACTUADOR PARA DERECHA
OPERATOR ON THE RIGHT
OPÉRATEUR À DROITE


INTERNO
INWARD


INTERNO
INWARD

Fig.1

Fig.2

Fig.3





FORARE L'ANTA E MONTARE IL GRUPPO SERRATURA SUI DUE LATI; COLLEGARE IL FILO DI SBLOCCO COME MOSTRATO IN FIG. 3
HORADAR LA PUERTA Y MONTAR EL GRUPO CERRADURA EN AMBOS LADOS; CONECTAR EL CABLE DE DESBLOQUEO COMO EN FIG. 3
DRILL THE DOOR AND MOUNT THE LOCK BLOCK ON BOTH SIDES; CONNECT THE RELEASE WIRE AS SHOWN IN FIG. 3
PERCEZ LA PORTE ET MONTEZ LE GROUP SERRURE SUR LES DEUX CÔTÉS; CONNECTER LE FIL DE DÉVERROUILLAGE COMME EN FIG. 3

